

Step 1: Slide the magazine into the loader then push the head of the loader.



Step 2: Insert the cartridge on the magazine.



Step 3: Realease the head of the loader.



Step 4: Push the cartridge.



Step 5: Reapeat the sequence.

USE SILICONE GREASE WHEN NEEDED

Designed and developed by Cap Création SAS - 06/21- contact@easypasters.com